



Hunter

Wireless Controller for Original XBOX, Switch & PC

CAUTION!

There are separate firmware updates for the XBOX DONGLE and the USB DONGLE.

DO NOT update your dongle with the wrong firmware or you will brick it.

Both Firmware updates are available on the website, please verify you are using the correct one before proceeding.

USB Dongle Firmware 2.0 Update Instructions

1. Download File and unzip on your computer.
USB Dongle firmware is named:
"USB Dongle Firmware - BM-973(MY-X19)-2024-0419(8A0C2A3C).zip"
2. Plug in the USB dongle to PC.
3. Press the button behind the controller to sync to dongle
4. Open the update program "BM-973(MY-X19)-2024-0419 (8A0C2A3C).exe"
5. Press the START button in program to update.
6. Your controller is now updated and you can close out program.

If you need further help, please reach out to support@retrofighters.com.

RETRO[®] FIGHTERS

Hunter

Wireless Controller for Original XBOX, Switch & PC

CAUTION!

There are separate firmware updates for the XBOX DONGLE and the USB DONGLE.

DO NOT update your dongle with the wrong firmware or you will brick it.

Both Firmware updates are available on the website, please verify you are using the correct one before proceeding.

XBOX Dongle Firmware 4.0.4 Update Instructions

1. Download File and unzip on your computer.
Xbox Dongle firmware is named:
"Xbox Dongle Firmware - BM-618F(MY-X19)-V4.0.4 2024-04-01.zip"
2. Plug in the XBOX dongle to a USB-C to USB-A cable and plug into computer for updating.
3. Connect the Controller to dongle by pressing middle button (if previously synched) or button behind controller.
4. Open update program "BM-618F(My-X19)-V.4.0.4.exe"
5. Hold left arrow button on controller and "A" at the same time for a few seconds until you hear a chime on computer, should be about 3-5 seconds.
6. Press START on the program.
7. Once updated you can disconnect dongle from PC and now use normally.

If you need further help, please reach out to support@retrofighters.com.