

FOR USE WITH

XBOX®

SWITCH

PC

SOCIAL

MEDIA

Be sure to follow us for the latest news and product releases.

retrofighters

retrofightersco

retro.fighters

retrofighters

Tag #retrofighters for a chance to be featured on our social media!

RETRO®

FIGHTERS

HUNTER

WIRELESS GAMEPAD


Quick Start

Instruction Manual



2.5 hours of charging

10 hrs. of gaming!



1 Left Analog Stick

2 Right Analog Stick

3 LED Indicators

4 X on XBOX, Y on Switch

5 Y on XBOX, X on Switch

6 A on XBOX, B on Switch

7 B on XBOX, A on Switch

8 White Button on XBOX, Home on Switch

9 Black button on XBOX

10 D-pad

11 Connection Button

12 Left trigger, ZL on Switch

13 Right trigger, ZR on Switch

14 LA on XBOX, Select on Switch

15 RA on XBOX, Plus on Switch

notes

customer service

We strive to make our fellow gamers happy. If you experience any issues with this product please contact us directly. We are here to help and we will make it right! You can send us an email at: support@retrofighters.com

how to pair

XBOX:

Plug in XBOX dongle, press the middle (3 arrows) button and it will connect.

Switch:

Make sure "Pro Wired Communication" is turned to "ON" in the Switch system settings. Plug in the USB wireless dongle and press the middle (3 arrows) button and it will connect.

PC:

1. Plug in the USB wireless dongle.

2. Press Home (middel elliptical button ) button to pair.

3. If cannot pair, press the back reset button.

Xinput to Dinput mode

Controller defaults to Xinput to change to Dinput press and hold the home button for at least 3 seconds, you will then switch to Dinput mode. Press home again to switch to Dinput digital mode. Repeat process to go back to Xinput.

LED indicators

● Player 1

●

●

●

●

● Player 2/XInput

●

●

●

●

● Player 3

●

●

●

●

● Player 4

●

●

●

●

macros

Power Off Gamepad

L3 + LEFT Arrow button

Increase Rumble

Left Joystick UP + RIGHT Arrow button

Decrease Rumble

Left Joystick DOWN + RIGHT Arrow button

FAQs

How do I pair my controller?

Please refer to the "How to Pair" section of this instruction manual.

Are the buttons analog?

Yes, the buttons are analog so you'll have no problem pulling off your favorite moves!

What systems are compatible?

XBOX/Switch/PC.

How do I charge?

To charge, use the provided USB-C cable with a USB compatible charging block (not included). Once charging the LED light on the controller will continuously blink indicating it is currently charging. Once the controller is fully charged it will stop blinking. This process takes approximately 2.5 hours on low / empty battery.

How long is the battery life?

Approximately 10 hours before you need to recharge.