


RETRO[®]
FIGHTERS

battler
wireless **gamepad**

Quick Start
Instruction Manual





- 1 Analog Stick (Left)
- 2 D-Pad
- 3 Analog Stick (Right)
- 4 LED Indicator
- 5 B Button
- 6 A Button
- 7 Y Button

- 8 X Button
- 9 Turbo
- 10 Screen Shot (Switch only)
- 11 "-" Button (Switch only)
- 12 "+" Button (Switch only)
- 13 L1 Shoulder Button
- 14 R1 Shoulder Button

- 15 L2 Trigger (Back)
- 16 R2 Trigger (Back)
- 17 Pairing Button
- 18 Home (Switch)
- 18 Start (GameCube)

setup (Switch)

Make sure that you turn on "Pro Wired Communication" in your Switch System settings otherwise your gamepad will not connect. Connect using the top pairing button.

how to pair

1. Insert the dongle into the controller port you want to use.
2. Press the "Home" button and 4 LEDs flash.
3. Press the back pairing button to automatically pair the controller.

powering off

Press L3 + "-" to turn off your gamepad.

Xinput to Dinput mode

Press "Home" button for approximately 3-5 seconds to swap Dinput.

turbo

Press the button you would like to activate turbo and press "T" turbo button at the same time. To deactivate, Hold the button you set and press "T" button at the same time.

LED indicators

- Player 4
- Player 3
- Player 2/Dinput Mode
- Player 1

FAQs

How do I charge?

Use the provided USB-C cable with a USB compatible charging block (not included). Once charging the LED light on the controller will continuously blink indicating it is currently charging. Once the controller is fully charged it will stop blinking. This process takes approximately 2.5 hours on low / empty battery.

How long is the battery life?

Approximately 10 hours before you need to recharge.

What systems are compatible?

The gamepad is compatible with GameCube, Wii, Wii U, PC & Switch.

Is this compatible with the official Wii U GC Adapter?

Yes, it is compatible with the official Wii U GC Adapter and most 3rd party brands.

How do the triggers work? They work with all games that require analog triggers, however there isn't a separate "click". To activate the digital function you just have to reach the end of the full range of the analog triggers.

customer service

We strive to make our fellow gamers happy. If you experience any issues with this product please contact us directly. We are here to help and we will make it right!
You can send us an email at: support@retrofighters.com

notes

social media

for use with
GameCube[®]
Switch • Wii • Wii U

Be sure to follow us for the latest news and product releases.



retrofighters



retrofightersco



retro.fighters



retrofighters

Tag **#retrofighters** for a chance to be featured on our social media!