



Hunter

Wireless Controller for Original XBOX, Switch & PC

CAUTION!

This firmware is for the XBOX DONGLE ONLY

DO NOT update the USB DONGLE

(updating the USB dongle with this firmware will brick it)

XBOX Dongle Firmware 4.0.4 Update Instructions

1. Download Files and unzip on your computer.
2. Plug in the XBOX dongle to a USB-C to USB-A cable and plug into computer for updating.
3. Connect the Controller to dongle by pressing middle button (if previously synched) or button behind controller.
4. Open program BM-618F(My-X19)-V.4.0.4.exe
5. Hold left arrow button on controller and "A" at the same time for a few seconds until you hear a chime on computer, should be about 3-5 seconds.
6. Press START on the program
7. Once updated you can disconnect dongle from PC and now use normally

If you need further help, please reach out to support@retrofighters.com.